

**IC408** 

# **Switch-mode Cigar Travel Adaptor**

Item ref: 661.408UK

User Manual

#### **Function:**

This compact, energy efficient switch-mode power supply gives up to 1000mA at 12Vdc and is supplied with 4 detachable plugs making it usable in most countries around the world.

4 plugs supplied (UK, European, American and Australian)
Uses 25% less power making it more energy efficient
Materials used and manufacturing process are more environmentally friendly

#### **Technical data:**

Input Voltage: AC 100 - 240V 50/60Hz

Output Voltage: DC 12 V

Output current: 1000mA max.

Output power: 12W

### **Instructions:**

- 1. Please read these instructions fully before using this apparatus.
- 2. Check the housing for damage.
- 3. Connect the unit to be powered to the cigar lighter socket.
- 4. The unit to be powered **must not** draw more current than the maximum continuous current of the power supply, in order to prevent overload. (The continuous current draw, should be no more than 80% of the output current max.).
- 5. Plug the power supply into a wall outlet.
- 6. The Red LED indicator will light.



## **Warning:**

- 1. For indoor use **ONLY**.
- 2. Risk of electric shock, **do not open**.
- 3. **Do not** install and operate the device in extreme heat, moisture or dusty environments.
- 4. **Unplug** the power supply when not in use.
- 5. The appliance is not intended for use by children or infirm persons without supervision.
- 6. This appliance is <u>not</u> intended for use by persons (include young children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 7. Young children should be supervised to ensure they do not play with the appliance.
- 8. This unit is double insulated.

#### **Disposal:**



Please dispose of this device according to the current statutory requirements.